

Black & Decker - Workmate WM 325 & WM 225

WARNING

When clamping a tapered workpiece (Fig 12) adjust vicebars to approximately the taper of the workpiece before applying any clamping pressure. Then tighten vicebars onto workpiece by means of approximately equal movement of both handles. When clamping any object close to one end of the vicebars use the handle at the same end to apply the clamping force required. Only slight force should be applied by the other handle if found necessary.

NOTE. Failure to follow these procedures will cause damage either to the workpiece or to the Workmate.