


OBSOLETE
PARTS MAY NOT BE AVAILABLE



UNIT DISCONTINUED *Apr. 10, 1978*

Item No.	Part No.	Description	Qty.	Item No.	Part No.	Description	Qty.
1	723031-38	Base Frame	1	21	723138	Half Nut (Top)	2
2	723154	Leg Spring	4	22	723085	Half Nut (Bottom)	2
3	723157	Leg <i>723225</i>	4	23	975236	8-32 x 9/16 P.H.M. Screw	4
4	904627	Adjustable Foot	8	24	075150	Nylatron Washer	4
5	723156	Spring Plate	4	26	723101	Screw	2
6	723001	Axle	4	27	975347	Roll Pin <i>976029</i>	4
7	723049	Catch	2	28	723056	Vise Screw	2
8	723129	Slide Bracket	4	30	975193	Handle Assembly <i>975142</i>	2
9	723051-38	L.H. Vise Bracket	1	31	131641-01	Vise Jaw & Label (Includes Item 16)	2
10	723088	L.H. Latch Lever	1	33	51332	Flat Washer	4
11	723105	Nylatron Washer	2	35	994459	"H" Frame <i>SEE Price list</i>	2
12	723000	Push-on Retainer	4	36	075154	Nylatron Washer	8
13	723094	Spring	2	37	975365	Cup Washer	8
14	723047-38	R.H. Vise Bracket	1	38	075155	Nylatron Washer	8
15	723064	R.H. Latch Lever	1	39	723098	Screw	8
16	<i>976066</i>	Caution Label	1	40	723040-38	Side Stay	2
17	99248-06	8-32 x 3/8" Screw	8	41	99247-04	6-32 x 1/4" P.H.M. Screw	4
18	81952	8-32 Hex Nut	8	42	12226	6-32 Hex Nut <i>742441-00</i>	4
19	723100	Screw	4	45	<i>975004</i>	Swivel Grip <i>735693</i>	4
20	723102	Screw	2	46	Eq 029	Blank NP <i>825011-00</i>	1

723064

IMPORTANT!—To assure product SAFETY and RELIABILITY, repairs, maintenance and adjustment should be performed by BLACK & DECKER Service Centers or other qualified service organizations, always using BLACK & DECKER replacement parts.

WHEN ORDERING REPLACEMENT PARTS YOU MUST GIVE UNIT, TYPE AND CATALOG NUMBER AS SHOWN ON NAME-PLATE, PLUS PART NUMBER AND NAME OF PART NEEDED.

WORKMATE

Cat. No.	Type
79-001	5

Black & Decker (U.S.) Inc.
Towson, Maryland 21204

Printed in U.S.A.	Bulletin No. 9106
-------------------	-------------------

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.