



WORKMATE SERVICE SHEET 79-001 TYPE E

Item No.	Part No.	Description	Qty	Item No.	Part No.	Description	Qty
1	994528	Slide Bracket (L/H)		30	895103	Wood Screw	2
2	994643	Vise Pad	2	31	745	Washer	4
3	892474	Top Half Nut	2	32	994840	Screw	4
4	892475	Bottom Bracket	2	33	894340	Vise Bracket (R/H)	
5	892473	Screw	4	34	999040	End Cap	2
6	994910	Latch S.A. (R/H)		35	895104	Bush	2
7	994527	Slide Bracket (R/H)		36	893157	Screw	2
8	994909	Latch S.A. (L/H)		37	894387	Vise Jaw	2
9	994856	Spacer	2	38	995331	Insert	10
10	894627	Adj Foot	4	39	994459	'H' Frame	
11	994839	Coil Spring	4	40	994904	Screw	2
12	22977	Drive Screw	8	41	995228	Top Leg Link (R/H)	2
13	995327	Pin	4	42	995227	Top Leg Link (L/H)	2
14	992738	Washer	38	43	994875	Rear Leg	
15	994691	Front Leg (R/H)		44	995319	Front Leg S.A. (R/H)	
16	994688	Front Leg (L/H)		45	995318	Front Leg S.A. (L/H)	
17	894628	Fixed Foot	4	46	994801	Screw	2
18	994838	Screw	18	47	995230	Swivel Grip	4
19	992404	Washer	10	48	894341	Vise Bracket (L/H)	
20	994841	Screw	6	49	896765	Wood Screw	2
21	994865	Base Bracket (R/H)		50	D7838	Rivet	2
22	894364	Side Stay	2	51	995332	Insert	10
23	994868	Handle S.A.	2	52	895102	Screw	2
24	994901	Handle	2	53	899211	Foot Panel S.A.	
25	994638	Thrust Bush	2	54	996838	Washer	2
26	995328	Thrust Washer	2	55	893714	Push On Fix	4
27	994727	Tension Pin	4	56	30251	Washer	2
28	892476	Vise Screw	2				
29	994864	Base Bracket (L/H)					



**IMPORTANT!**— To assure product SAFETY and RELIABILITY, repairs, maintenance and adjustment should be performed by BLACK & DECKER Service Centers or other qualified service organizations, always using BLACK & DECKER replacement parts.

**WHEN ORDERING REPLACEMENT PARTS YOU MUST GIVE UNIT, TYPE AND CATALOG NUMBER AS SHOWN ON NAMEPLATE, PLUS PART NUMBER AND NAME OF PART NEEDED.**

**WORKMATE**  
 Cat. No.            Type  
 79-001                E

The Black & Decker Mfg. Co.  
 Towson, Maryland 21204

Printed in U.K.